

Copy and Paste Specifications

Acoustic Socket Boxes – Robust Detail Compliant



- **Manufacturer:**

- **Sound Reduction Systems Ltd**
- Web: www.soundreduction.co.uk
- Email: info@soundreduction.co.uk
- Tel / Fax: 01204 380074 / 01204 380957
- Product Ref: *Acoustic Socket Boxes*

- **Installation Detail:**

- Cut suitable sized hole in plasterboard / Maxiboard.
- Remove rear knockout from the metal tray and drill corresponding holes in the Acoustic Socket Box to allow for cable routing.
- Apply bead of SRS Gripfix to front edge of Acoustic Socket Box and push into place.
- From the front, fix through the plasterboard / Maxiboard and into the softwood bearers in the Acoustic Socket Box using two 25mm Drywall screws.
- Note: Acoustic Socket Boxes should not be located back-to-back.

- **Notes:**

- This specification is not a substitute for the manufacturer's installation guide. Please contact SRS Ltd for full installation instructions and details of approved stockists.